



# Iron-A-Way®

## How to Install Mirror & Brackets

### Tools Needed

- Electric drill with 5/64" drill bit
- Philips Screwdriver bit



**Questions?**  
Give us a call at 1-800-536-9495  
or email [support@ironaway.com](mailto:support@ironaway.com)



### IMPORTANT NOTE:

Instructions assume installation of mirror on unit that has not yet been mounted on the wall or recessed.

If painting or staining of door or cabinet exterior is desired, it is recommended to do so before beginning mirror installation.

*If attaching to an already installed unit, it is recommended to have a partner assist with these instructions, with slight adjustments to steps.*

1



### Inspect mirror

Before beginning installation, inspect mirror for possible shipping damage.

2



### Lay mirror on unit

With new unit on floor, lay mirror on top of unit door.

3



### Install brackets

Slip brackets over each end of mirror. Holes will lay against bottom of door (not on mirror) so screws can be applied into the wood of the door.



#### Pre-drill holes

Pre-drill a pilot hole into each screw using a 5/64 drill bit.



#### Install bracket screws

Drive small wood screws into each hole located on bracket. Your mirror is now installed and unit is ready to be mounted or recessed.



#### Remove tape

After your ironing center is installed remove protective tape from brackets.

***Installation Complete!***

Questions?  
Give us a call at 1-800-536-9495  
or email [support@ironaway.com](mailto:support@ironaway.com)

